



SWTgo User's Guide



General Safety Information

The user assumes all risk and liability with use of this item.

- ◆ Care must be taken to avoid injury due to falling or other associated risks.
- ◆ Use the unit with caution if you are unsteady on your feet. You must be able to climb a ladder in order to use this tent on top of your vehicle.
- ◆ This tent is designed to **hold a maximum of 500lbs, or two adults**. Do not exceed this maximum.
- ◆ The tent shell temperature range is 0°-120° F. Remember to take precautions against extreme temperatures when camping as the tent is not insulated.
- ◆ Do not use any heating sources in or near the tent that emit poisonous fumes to prevent poisoning or asphyxiation.

Packing List

- ◆ 1 tent
- ◆ 1 telescoping ladder
- ◆ 1 package of mounting brackets, bolts, and nuts
 - a. 8 brackets
 - b. 8 bolts
 - c. 8 nuts
- ◆ 1 kick pad
- ◆ 1 privacy fly
- ◆ 1 lantern

Installation Instructions

Refer to silverwingtents.com for more videos and installation instructions

NOTE: Many rack systems have a tight clearance between the roof and the rack, or are not strong enough. This may make installation difficult. You may purchase an aftermarket rack system that will make installation easier if necessary.

CAUTION: You will need at least **2 people to install the SWT90 safely**. You will not be able to lift it with one person

1. Unpack tent with care to avoid scratching the surface of the shell.
2. Take 4 brackets and the 8 bolts. In each plate, place one bolt into a hole on each end (Fig. 1).
3. Insert two brackets (with bolts still attached) into one end of each channel, located at the bottom of the tent shell. Slide them so they approximately match your rack spacing. You will want one bracket near each corner of the tent



Fig. 1

The brackets, bolts, and nuts.

Place the bolts on both ends of the bracket. Which hole you place the bolts in will depend on the width of your vehicle rack.

4. Lift tent onto the top of your rack system. **Lifting the tent will require two people.**
5. If brackets are not aligned properly with the front or back racks, adjust them accordingly. One bolt must be on one side of the rack, and the other bolt on the other side for each bracket.



Fig. 2

Each set of two brackets should look like this beneath your vehicle rack. Remember, the bolts should be on either side of the rack.

6. Insert the remaining 4 brackets onto the bolts and loosely attach with a nut on each bolt (Fig. 2). This bottom bracket will go underneath the rack.
7. Adjust the tent (if needed) so it is square and centered on your vehicle, and adjust to remove interference with any doors.
8. Tighten nuts until tent is snug and cannot slide.

General Usage Instructions

Opening the Tent

1. There are four latches and four buckles on the tent, located in the front and back. Unhook the buckles and unlatch the latches. Push the tent up and it will pop open on its own.
2. You will find the ladder inside the tent. Open and extend the ladder to the required length. Attach to the tent using the security straps, found under the entrance door.

Always make sure your ladder is securely fastened to the tent before entering or exiting the tent.

Closing the Tent

1. Collapse the ladder and place it back into the tent for storage if desired.
2. Remove foam pads under each collapsible gas strut to make closing easier. Insert entry awning into tent.
3. There is a strap handle located on the outside at each end of the tent. Begin by collapsing one end and very loosely attach the two security straps. (Be sure to do this LOOSELY or you will break the strap buckle). Then proceed to collapse the other tent end and tuck any loose fabric inside. Ensure all fabric and contents are securely in place.
4. Once tent is fully closed and all the fabric tucked into the shell, secure all latches and tighten all buckles.

Traveling with the Tent

- ♦ Buckle lid on tightly before traveling any distance. Always make sure to double check that your tent and mounting brackets are secure.
- ♦ After 25 miles, stop and check that the tent is secure and has not shifted. You must also periodically continue to check your tent if you are traveling long distances

You must not exceed 75 mph when traveling with the tent

Caring for Your Tent

- ♦ When cleaning, only use cold water and a soft brush. Never use soap or detergent.
- ♦ Do not expose fabric to oil or solvents
- ♦ Expect some weeping at the seams of the fabric with the initial use. This will reduce with use and as the fabric cures
- ♦ As the tent is used, it is recommended that you occasionally re-proof the fabric with a high quality water-proofing solution to keep the tent in good condition.
- ♦ Always store tent up off the floor and away from damp areas.
- ♦ Periodically and every season ensure that all bolts and nuts are tight to reduce any damage from use.
- ♦ Do not drag tent on the ground as this could damage the fabric and allow water seepage when used.

Consult with your local outdoor equipment dealer, automotive dealer, or Silverwing Tents for any questions. Contact us at info@silverwingtents.com



Silverwing Tents will inspect any claim prior to repair to determine the defect. Misuse, adjustments, alterations, abuse, overloading, improper loading, damages resulting from failure to check and secure bolts correctly, acts of God, or accident is not included in the warranty.

Silverwing Tents will not be responsible for accidents, incidental, indirect, special, or liable damages to persons or property which may result from a defect in workmanship or material. Silverwing Tents is not responsible or liable for damages including (but are not limited to) loss of income, loss of time, and any other costs or fees associated with any warranty issue or claim.

The purchaser will be responsible for any freight costs incurred to transport the tent as directed by Silverwing Tents to its authorized dealer or the Silverwing Tents factory location.

Any repairs or claims must be pre-approved and authorized in writing from Silverwing Tents. The warranty shall be null and void in the event the tent has been subject to modifications, misuse, neglect, accident, and overloading.

See silverwingtents.com or email info@silverwingtents.com for more information.